### HEIGHT ADJUSTABLE TABLES ASSEMBLY INSTRUCTIONS


# **Offices**to**Go**

#### **OTGHABASE2**



### HEIGHT ADJUSTABLE TABLES ASSEMBLY INSTRUCTIONS

#### **EXPLODED VIEW**




#### **HARDWARE LIST**

A x 8+2 (M8x20)	B x 10+2 (M6x8)	C x 2+2 (M6x12)	D x 8+2 (M6x10)	E x 8+2 (ST4.8x20)	F x 6+2 (ST3x19) (packed with handset and power supply)
G x 2	H x 1 (4mm)	l x 1 (5mm)	J x 1	K x 2+2	

### HEIGHT ADJUSTABLE TABLES ASSEMBLY INSTRUCTIONS

#### STEP 1 - Assemble Cross Rail


- Do not tighten these screws until after Step 4.
- Leave screws loose enough to easily slide brackets along slot.



<u></u>	<b>S</b>
H x1	C x2

#### STEP 2 - Affix Motor

 Affix motor unit to right leg (item 8).






#### **HEIGHT ADJUSTABLE TABLES ASSEMBLY INSTRUCTIONS**

J x1


#### STEP 3 - Assemble legs and crossrail

· Connect cross rails to legs, leave screws from Step 1 loose.



#### **STEP 4 - Connect Hex Rods**


- · Insert hex rod into motor (Item 12) and slide tube over the hex rod in left leg (Item 2).
- · Slide mechanism to desired size.
- · NOTE: Table top should overhang base on the left and right side by a minimum of 1" and a maximum of 2.25".
- · Tighten knobs on the tube (Item 4).



### HEIGHT ADJUSTABLE TABLES ASSEMBLY INSTRUCTIONS


### STEP 5 - Assemble end brackets and insert spacers

- Plastic spacers (Item K) should be placed evenly on the center portion of the crossrail.
- · Tighten all screws securely.



#### **STEP 6 - Assemble Table Top**

- Center frame (on all sides) on the bottom of the table top. Use screws (Item E) to assemble base frame to the bottom of the table top.
- Tighten screws securely.
- NOTE: Table top should overhang base on the left and right side by a minimum of 1" and a maximum of 2.25".





#### **HEIGHT ADJUSTABLE TABLES ASSEMBLY INSTRUCTIONS**

**STEP 7 - Assemble Power** 

Supply and Handset • Tighten screws securely.  $\coprod$ 9 Fx6